

EYRUS HAND SCANNER


Quick Start Guide

A quick guide to setting up your Eyrus Visibility app with a hand scanner.

Login to the Eyrus Visibility App and select your project and zone (the area where you are checking people in).


Confirm you have selected the right zone every time you use the scanner.

You can change your zone in settings or by tapping the zone name in blue.



Select Access Control Mode

- Select "Sort by access"
- Choose to set a direction (everyone is scanned in or out). You can leave this unchecked and choose in/out each time you scan.
- If setting a direction, select automatically check in/out.
- We recommend setting Timeout to "1 Minute"
- If using only NFC badges on your site, we recommend going to settings, and selecting "NFC Only"



EYRUS HAND SCANNER


Quick Start Guide

Tap “get started” and you’ll be ready to scan.

When tapping an NFC badge the person's profile card will automatically display with their permission to the selected zone.

Granted workers are automatically checked-in or out when a fixed direction is set.

Denied workers will require a manual tap by the app user to record the IN or OUT attempt.



**Hand scanner trigger. If your hand scanner cradle came with a trigger, please know that the trigger does not cause a badge scan. The scan will happen automatically as the badge gets near enough.*